

VIREX

PEROXYGEN BASED DISINFECTANT FOR SURFACES, EQUIPMENT & WATER SYSTEMS

- **Effective against major viral, bacterial and fungal pathogens**
- **DEFRA approved for Foot and Mouth, Swine Vesicular Disease, Diseases of Poultry & General Orders**
- **Safe to the operator. Non-corrosive at in use dilution**
- **Biodegradable**



RECOMMENDED USAGE



Virex can be used for terminal disinfection.


Surface / Equipment Disinfection: apply at 1:300 and 300ml/m²– Use a pressure washer at low pressure (500 psi) or a foam lance.

Fogging; a 4% solution of Virex can be fogged at a rate of 20L per 1000 sqm.



DEFRA Approvals

Foot and Mouth Disease: 1 part VIREX in 1300 parts water.
Swine Vesicular Disease: 1 part VIREX in 100 parts water.
Diseases of Poultry: 1 part VIREX in 100 parts water.
General Orders: 1 part VIREX in 100 parts water.



Water Sanitisation during terminal disinfection:

Dose header tank at 1:200 and drain system. Leave for one hour and flush with clean water.

Foot dip use: Dissolve 1 soluble sachet in 10 litres of water. Stir until dissolved. Dilution rate 1:100.

Virex has been independently tested using EN test methods against the causative agents of;

Chicken anaemia	Gumboro	Avian Influenza	Egg Drop Syndrome
Aujesky's	Tenosynovitis	PCV2	Parvoviral Enteritis
Porcine Blue Ear / PRRS		Infectious Bovine Rhinotracheitis	

Virex has proven effective in independently tests using EN test methods against

Bacillus	Campylobacter	Clostridium	Enterococcus	E. coli	Haemophilus
Helicobacter	Listeria	Proteus	Pseudomonas	Salmonella	Staphylococcus
Streptococcus	Vibrio	Candida	Dermatophilus	Microsporium	Trichophyton

Pack size: 5, 10 & 20 kg, Sachets 95x100g

Storage: Store in a cool, dry place in the original container. Keep pack tightly closed.

Shelf Life: 2 years from date of manufacture

USE BIOCIDES SAFELY. ALWAYS REFER TO THE PRODUCT LABEL AND SAFETY DATA SHEET BEFORE USE

KILCO (INTERNATIONAL) LTD.
BROOMHOUSES 2 INDUSTRIAL ESTATE
OLD GLASGOW ROAD, LOCKERBIE.
DG11 2SD

Tel: +44 (0) 1576 205 480
Fax: +44 (0) 1576 205 483
Email: enquiries@kilco.co.uk

